

Immax
max NEO LITE Smart IR ovladač
teploty a vlhkosti s LCD displejem
07559L

A black and white line drawing of the Immax max NEO LITE Smart IR remote control. The remote is rectangular with rounded corners and a large square LCD display in the center. To the right of the display is a small rectangular button. A USB cable is connected to the bottom of the remote, featuring a standard USB-A connector.

Snímač podsvícení LCD
- po aktivaci je podsvícení LCD aktivní po dobu 20 vteřin

Sklápecí stojan

Otvory pro zavěšení

Resetovací tlačítko
Jitřím kliknutím přepnete mezi °C a °F
Trojitým kliknutím přepnete mezi
minutovým a 24hodinovým formátem

1,5m USB kabel

Barva: černá
 Protokol: Wi-Fi IEEE 802.11b/g/n
 Frekvence: 2400MHz~2483.5MHz
 Maximální RF výstupní výkon: WiFi: 20dBm
 Frekvence IR: 38KHz
 Dosah IR: 12 metrů
 Rozsah detekce vlhkosti: 0-90% RH
 Přesnost měření vlhkosti: $\pm 5\%$ RH
 Rozsah detekce teploty: 0 - $+60^{\circ}\text{C}$
 Přesnost měření teploty: $\pm 1^{\circ}\text{C}$
 Materiál: plast
 Stupeň krytí: IP20
 Napájení: DC 5V / 1A (1,5m USB kabel)
 Rozměry: 8 x 8 x 1,6cm
 Obsah balení: IR ovladač, uživatelský manuál



IMMAX NEO PRO APP

Provedte reset zařízení – stiskněte resetovací tlačítko na produktu na více než 5 vteřin. Ikona stisk na LCD zařízení začne blikat.

Pokud nemáte zapnutý Bluetooth na svém mobilním zařízení, tak je zapněte.

V aplikaci klikněte na tlačítko „+“, vyčkejte až aplikace vyhledá zařízení a potom klikněte na tlačítko „Přidat“. Zadejte přístupové údaje do WIFI sítě a potvrďte. Potom se daný produkt spáruje a přidá aplikace Immaxx NEO PRO

Provedete reset zařízení – stisknete resetovací tlačítko na produktu na více než 5 vteřin. Ikona síťe na LCD zařízení začne blikat.

V aplikaci Immax NEO PRO klikněte na tlačítko „+“ pro přidání zařízení. V záložce Immax NEO vyberte produkt (nebo zvolte univerzální možnost Ostatní WiFi zařízení).

Zadejte přístupové údaje do WiFi sítě a potvrďte. Potom se daný produkt spáruje a přidá do aplikace Immax NEO PRO.

této kartě potom klikněte na tlačítko „Přidat“ a vyberete typ zařízení, které chcete přidat. V pravém horním rohu klikněte na „Rychlé přidání“ a nebo „Manuální přidání“ a postupujte dále dle instrukcí v aplikaci.

UPOZORNĚNÍ: Uchovávejte mimo dosah dětí. Tento výrobek obsahuje malé součástky, které mohou způsobit udušení nebo zranění při požití.

VAROVÁNÍ: Každá baterie má předpoklad k úniku škodlivých chemikálií, které mohou poškodit pokožku, oděv nebo prostor kde je baterie uložena. Abyste předešli zranění, nedotýkejte se baterie jakoukoliv látkou z baterie přišla do kontaktu s očima nebo pokožkou. Každá baterie může prasknout či dokonce explodovat, pokud je vystavena ohni nebo jiným formám nadměrného tepla. Během manipulace s bateriemi buďte opatrní. Pro snížení rizika či následků způsobené nesprávným zacházením s bateriemi proveďte následující opatření:

- Nepoužívejte různé značky a typy baterií ve stejném zařízení
- Při výměně baterií vždy vyměňte všechny baterie v zařízení
- Nepoužívejte dobíjecí nebo opakovaně použitelné baterie.
- Nedovolte dětem instalovat baterie bez dohledu.
- Dodržujte pokyny výrobce baterie pro správnou manipulaci a likvidaci baterie.

UPOZORNĚNÍ: Výrobek a baterie by měly být likvidovány v recyklačním centru. Nevyhazujte s běžným odpadem z domácnosti.

UPOZORNĚNÍ: Pro zajištění bezpečného používání výrobku je nutné v místě instalace přivést vodiče dle platných předpisů. Instalace musí být provedena pouze osobou s odpovídající certifikací v oboru elektro. Při montáži nebo při zjištění závady, musí být vždy odpojeny přívodní kabel ze zásuvky (v případě přímého zapojení je nutné vypnout příslušnou jistič). Nesprávná instalace může vést k poškození výrobku a zranění.

UPOZORNĚNÍ: Neprovádějte demontáž výrobku, možnost úrazu elektrickým proudem.

UPOZORNĚNÍ: Používejte pouze originální napájecí adaptéry dodané s tímto výrobkem. Nevadíte zařízení do provozu, pokud přívodní kabel vykazujete známky poškození.

UPOZORNĚNÍ: Postupujte podle pokynů v přiloženém manuálu.

Údržba

Chraňte zařízení před kontaminací a znečištěním. Přístroj otvete měkkým hadříkem, nepoužívejte drsné nebo hrubozrnné materiály.

NEPOUŽÍVÁTE rozpouštědla nebo jiné agresivní čističe či chemikálie.

Zkrácená verze prohlášení o shodě
Tímto výrobce IMMAX prohlašuje, že typ rádiového zařízení 075S9L je v souladu se směrnicí 2014/53/EU. Úplné znění EU prohlášení o shodě je k dispozici na těchto internetových stránkách www.immax.cz, www.immax.eu
Bezpečnostní informace k tomuto výrobku si můžete stáhnout ze stránek www.immax.cz
Pokud máte dotaz nebo potřebujete poradit, kontaktujte nás na adrese podpora@immaxneo.cz

 vyjadřuje, výrobek nesmí být likvidován s komunálním odpadem. Pro správnou likvidaci výrobku jej odevzdejte na určených sběrných místech.

Při likvidaci vyjměte za zařízení baterie a žárovky – pokud to lze.

Střih spotřebič odevzdejte ve sběrnách k tomu určených, nepatří do komunálního odpadu.

Odpadní elektrická a elektronická zařízení ze soukromých domácností lze zdarma odevzdat na veřejných sběrných místech

Jako koncový uživateli odpovídá za výmaz osobních údajů ze starého spotřebiče ASEKOL: AK-016010, WEEE-Reg.-Nr. DE 88927148

Uživatelský manuál je možné stáhnout z webových stránek.
 Uživatelská příručka je možné stáhnout z webových stránek.
 The multilingual user manual can be downloaded from the website.
 Das mehrsprachige Benutzerhandbuch kann von der Website
 heruntergeladen werden.
 Wielojęzyczna instrukcja obsługi jest dostępna do pobrania na stronie
 internetowej.
 A többnyelvű felhasználói kézikönyv letölthető a weboldalról.



Immax
®

The image shows a black digital thermometer with a USB cable attached. The screen displays the following information: 26.3°C, 68°F, a battery level icon, and the date 18/02/2022. The time 16:19 is also shown.



Výrobce / Dovozce; Manufacturer / Importer: IMMAX, Teslova 1179/2,
702 00 Ostrava, EU www.immax.cz Navrženo v České republice,
vyrobena v Číně Designed in the Czech Republic, made in China

Immax
Immax NEO LITE Smart IR controller with
temperature and humidity sensors, WiFi
07559L

LCD backlight sensor
- (after activation, the LCD backlight remains on for 20 seconds)

Folding stand

Mounting holes

Reset button

Single-click to switch between °C and °F
Double-click to switch between 12-hour and 24-hour formats

1.5m USB cable

Color: Black
 Protocol: Wi-Fi IEEE 802.11b/g/n
 Frequency: 2400 MHz–2483.5 MHz
 Maximum RF Output Power: Wi-Fi: 20 dBm
 IR Frequency: 38 kHz
 IR range: 12 meters
 Humidity detection range: 0–90% RH
 Humidity measurement accuracy: $\pm 5\%$ RH
 Temperature detection range: 0–+60°C
 Temperature measurement accuracy: $\pm 1^\circ\text{C}$
 Material: plastic
 Protection rating: IP20
 Power supply: DC 5V / 1A (1.5m USB cable)
 Dimensions: 8 x 8 x 1.6cm
 Package contents: IR remote control, user manual

Scan the QR code to download the Immax NEO PRO app.
Or search for and install the Immax NEO PRO app in the App Store or Google Play.

- Launch the Immax NEO PRO app, tap “Register,” and create your own account.
- Once you have completed registration, log in to your account.



iMMAX NEO PRO APP

Reset the device – press the reset button on the product for more than 5 seconds. The network icon on the device's LCD will start flashing.

If Bluetooth is not turned on on your mobile device, turn it on.

After turning on Bluetooth, your mobile device will automatically detect the product. In the app, click the "+" button, wait for the app to find the device, and then click the "Add" button. Enter the

Wi-Fi network credentials and confirm. The product will then be paired and added to the Immaxx NEO PRO app.

Reset the device—press the reset button on the product for more than 5 seconds. The network icon on the device's LCD will start flashing.

In the Immaxx NEO PRO app, click the “+” button to add a device.

In the Immaxx NEO tab, select the product (or choose the universal option “Other WiFi Devices”).

Enter your Wi-Fi network credentials and confirm. The product will then pair and be added to the Immaxx NEO PRO app.

In the Immax NEO PRO app, click the Smart IR Controllers tab. On this tab, click the “Add” button and select the type of device you want to add. In the top-right corner, click “Quick Add” or “Manual Add” and follow the instructions in the app.

WARNING: Keep out of reach of children.

This product contains small parts that may cause choking or injury if swallowed.

WARNING: Any battery is capable of leaking harmful chemicals that can damage skin, clothing, or the area where the battery is stored. To avoid the risk of injury, do not allow any substance from the battery to come into contact with your eyes or skin. Any battery may rupture or even explode if exposed to fire or other forms of excessive heat.

Handle batteries with care. To reduce the risk of injury caused by improper battery handling, take the following precautions:

- Do not use different brands or types of batteries in the same device
- When replacing batteries, always replace all batteries in the device
- Do not use rechargeable or reusable batteries.
- Do not allow children to install batteries without supervision.
- Follow the battery manufacturer's instructions for proper handling and disposal of the battery.

WARNING: The product and batteries should be disposed of at a recycling center. Do not dispose of them with regular household waste.

WARNING: To ensure safe use of the product, wiring must be installed at the installation site in accordance with applicable regulations.

Installation must be performed only by a person with appropriate certification in the electrical field. During installation or if a fault is detected, the power cord must always be unplugged from the outlet (in the case of direct connection, the corresponding circuit breaker must be turned off). Improper installation may result in product damage and injury.

WARNING: Do not disassemble the product; risk of electric shock.

WARNING: Use only the original power adapter supplied with the product. Do not operate the device if the power cord shows signs of damage. **WARNING:** Follow the instructions in the included manual.

Maintenance
Protect the device from contamination and dirt. Wipe the device with a soft cloth; do not use abrasive or coarse materials.
DO NOT USE solvents or other harsh cleaners or chemicals.

A Declaration of Conformity has been issued for this product; for more information, visit www.immax.cz
If you have any questions or need advice, please contact us at podpora@immaxneo.cz

The manufacturer IMMAX hereby declares that the radio equipment type 075591 complies with Directive 2014/53/EU. The full text of the EU Declaration of Conformity is available on the following websites:
www.immax.cz, www.immax.eu
 Safety information for this product can be downloaded from www.immax.cz
 If you have any questions or need advice, please contact us at podpora@immaxneo.cz.

The symbol  indicates that the product must not be disposed of with household waste. For proper disposal, please take the product to designated collection points.

When disposing of the device, remove the batteries and light bulbs—if possible.

Please take your old appliance to designated collection points; it does not belong in household waste.

Waste electrical and electronic equipment from private households can be returned free of charge at public collection points

As the end user, you are responsible for erasing personal data from the old appliance ASEKOL: AK-016010, WEEE-Reg.-No. DE 88927148

Uživatelský manuál je možné stáhnout z webových stránek.
 Üzítársak kézikönyve letölthető a weboldalról.
 The multilingual user manual can be downloaded from the website.
 Die mehrsprachige Benutzerhandbuch kann von der Website
 heruntergeladen werden.
 Wielojęzyczna instrukcja obsługi jest dostępna do pobrania na stronie
 internetowej.
 A többnyelvű felhasználói kézikönyv letölthető a weboldalról.



CE RoHS

Výrobce / Dovoze; Manufacturer / Importer: IMMAX, Teslova 1179/2
702 00 Ostrava, EU www.immax.cz Navrženo v České republice,
vyrobena v Číně Designed in the Czech Republic, made in China